

CARA KOMMODE

A0132-106-0000
 A0132-106-0001
 A0132-106-0002
 A0132-106-0003
 A0132-106-0004



Montageanleitung/ Assembly instruction/ Instructions de montage/ Istruzioni per il montaggio

Ax1 	Bx4 	Cx1 	Dx1 	Ex1 	Fx2 	Gx3 	Hx2
Ix1 	J _R x3 J _L x3 	Kx12 (4x20) 	Lx18 (3,5x30) 	Mx4 	Nx8 	Ox8 	Px1
Rx20 (ø8x32) 	Sx28 (3,5x17) 	Tx4 					



