














CARA SCHRANK

A0132-101-0001-C1
A0132-101-0001-C2
A0132-101-0001-C3
A0132-101-0000-C1
A0132-101-0000-C2
A0132-101-0000-C3



Montageanleitung/ Assembly instruction/ Instructions de montage/ Istruzioni per il montaggio

A 1L+1R 	Bx1 	Cx1 	Dx1 	Ex5 	F 1L+1R 	Gx8 	Hx2 
Ix1 	Jx4 	Kx2 	Lx2 	M 1a+4b+1c 	N 2L+2R 	Ox8 	Px8 
Rx4 	Sx1 	Tx2 (ø6) 	Ux84 (ø8x32) 	Vx36 (4x20) 	Wx1 	Z1x8 	Z2x8 
Z3x8 	Y1x40 (4x40) 	Y2x42 (3,5x17) 	Y3x16 (3,5x30) 	Y4x2 (3,5x35) 			

