









BAJO 4
Artikel 4905734

Stückliste
Liste des pièces
Elementi in dotazione

	1x	Zeltsack Sac de tente Sacca per tenda
	1x	Innenzelt (Polyester) Tente intérieur (polyester) Tenda interne (poliestere)
	1x	Aussenzelt (Polyester) Double-toit (polyester) Tenda esterna (poliestere)
	1x	Zeltboden (Polyethylen) Sol de la tente (polyéthylène) Pavimento della tenda (polietilenica)
	25x	Heringe Piquets d'ancrage Picchetti di ancoraggio
	10x	Abspannleinen Haubans Tiranti
	2x	Fiberglasstangen 9-teilig Armature en aluminium de 9 pièces Aste in aluminium da 9 pezzi Ø 8,5 mm / 440 cm
	1x	Fiberglasstange 7-teilig Armature en aluminium de 7 pièces Aste in aluminium da 7 pezzi Ø 8,5 mm / 358 cm

Aufbauanleitung
Instructions de montage
Istruzioni per il montaggio

