



Instruction Manual

Girls Mini Car

W431E


- With forward and reverse drive
- Multi function steering wheel with sound and light functions
- Rubber tread band to prolong life of tyres and improve grip




Please read the instruction manual completely before attempting assembly and operation. An adult should only attempt the assembly.

This toy is not suitable for children under 3 years of age .


Assembly Instructions




To assemble the steering wheel
Push the wire connectors together (1a) and carefully assemble the steering wheel to the connector column. Slide the steering wheel assembly into the body of the car being careful not to pinch any of the wiring. The column and steering wheel will 'click' and lock together.




To assemble the front windshield
-Align the windshield with the car body locations. Push gently on the windshield frame until the screen clicks into the car body locators - the moulded clips should now secure this.




To assemble the rear spoiler -Align the spoiler with the locators in the rear of the car body. Gently push the spoiler into the body locations. The spoiler will lock into place when correctly located into the body-This should now be secured by the moulded clips.



To assemble the seat
Align the seat holes with the holes in the body, then using the self tapping screws supplied fix the seat using screws using a suitable screwdriver.




To assemble the rear wheels
Follow photo 5 diagram ensuring the wheel is fully located and the wheel nuts are tight before putting the wheel cap/trim on.



To assemble the front wheels
Follow photo 6 diagram ensuring the wheel is fully located and the wheel nuts are tight before putting the wheel cap/trim on.

Operation



To operate the car ensure the power switch is set to "1" position.




1. To move forward, push the "gear knob" to the forward position and press the yellow peddle switch. The car will move Forward. (be careful to avoid obstacles!!) The stop remove your foot from the peddle switch.
2. To operate the car in reverse, pull the "gear Knob" to the backwards position and press the Yellow peddle switch. The car will now reverse. (be careful to avoid obstacles!!)

Trouble Shooting

3. Do not switch between forward and reverse while the car is in motion as this may damage the car's transmission.


The steering wheel is multi functional with various synthesised sounds and the ability to switch on the lights- these are illustrated on Photo 2. Prolonged use of these functions will reduce the battery life so more frequent charging will be required.

To remove the battery unclip the boot lid and remove the battery clamp. Disconnect the wires from the battery and lift out the battery from the car body. To replace the battery insert the battery and reconnect the wires (red +ve) (Black -ve).



4. How to replace the fuse?
 a. Remove the screw which fixed the seat, take off the seat, and you will find the battery cabin.
 b. Open the fuse case, take out the spare fuse.
 c. Use the spare fuse to replace damaged one.
 d. Then shut the fuse case, and use the screw to tighten the seat.

Use of fuse



Attention: fuse type is 20A.

Trouble Type	Testing Parts	Tactics
No voice, No light Unmoved	1. battery terminal connector off. 2. power switch wrong. 3. the connector between power and driving board off.	reconnect ok. change it. reconnect to send the driving board to repair.
Have voice Have light Unmoved	1. pedal switch thoughts right? 2. turning switch ok? 3. engine run ok? 4. engine connector ok? 5. directly connect engine with battery change engine or does it run ok?	adjust pedal switch. change it. change gearbox or remove trouble. change connector. repair driving board.
Only front move no behind or converse	1. turning switch ok? 2. lead wire between turning key to circuit ok?	change it. reconnect or repair the Driven board.
Speed very slow	1. is the voltage over 6v? 2. connect engine with battery directly, speed up?	recharge battery. repair driving board. change case or engine.
Continue run	1. is the voltage over 6v? 2. driver overload?	recharge battery. yes, only for one child; no, check gear box.
Can't stop normally	1. pedal switch ok?	change the switch spring.
Battery can't be charge fully	1. output terminal have 6.8V-8.0V 2. insert the input end and output of end of charge, and pull out the two ends of battery, to check if have, 6.8V-8.0V voltage? 3. charger not tightend, welding fall off.	change charger. change battery. fix up the socket.
No voice Light flashed	1. broken horn.	change horn.
No voice	1. the sound key are not useful. 2. the down-lead fall off.	change sound key. change down-lead.
Continue voice	1. the switch is broken? 2. test the power socket for sound-light ears or ways.	revise the switch. revise the power socket.
Dark front light	1. test the bulb. 2. check the bulb socket and connect ways of deal?	change bulb. change power socket.
Can't drive	1. check the switch? 2. the down-lead fall off?	change switch. connect OK.
Can't stop	1. broken switch? 2. test the pedal switch?	change switch. amend switch.

Specification

BATTERY	6V 7Ah CHARGEABLE BATTERY
MOTOR	6V 20W
AGE RANGE	3-8 YEARS
MAX. LOAD	35 Kg
DIMENSIONS	1000x600x590 mm
SPEED	3-4 Km/h
CHARGER	OUTPUT DC7.8V, INPUT AC230V/50HZ
RUNNING TIME	CHARGE 8-12 HOURS, DRIVE 1-2 HOURS
FUSE	20A

The cautions of charge

1. Before your first driving, charge the battery for 12 hours before the vehicles first used.
2. The socket for charge is just in the afterbody. Put the charge's DC plug into the socket, and then put the charger into the 230V power source's socket.
3. Please charge 8-12hrs, after driving 1-2hrs, the charge time can not exceed 20hrs.
4. When the marching speed is slower than the normal level, recharge right now for 8-12hrs.
5. If the car has a long time not being used, please charge full the cell, then charge once per 3 months, to extend the cell's life.
6. If the charger is hot(under 71°)while charging, that's normal.
7. The socket of the charger can't have water, or may happen short circuit.
8. The car must use the special charger furnished with it, to avoid damage the charger storage cell or circuit.
9. Charging cell must be by adults.
10. Non-rechargeable batteries are not to be recharged.
11. Only batteries of the same or equivalent type as recommended are to be used.
12. Batteries are to be inserted with the correct polarity.
13. Exhausted batteries are to be removed from the boy.
14. The supply terminals are not to be short -circuited.

Driving attention

1. Must not ride on the street, highway, slope, sand, or any dangerous places.
2. Must ride on even ground.
3. Must ride without overload.
4. Charging cell must be by done adults.
5. Children's riding must be guided by adults.
6. Please do not change the circuit of the vehicle or it's attaching electric equipments.
7. Please do not ride in water, or other fluid to the vehicle.
8. Do not push Backward/Forward when riding.
9. When meeting barriers, just loosen the pedal switch, turn away from the barriers, march on.
10. Please charge in time when the vehicle runs slowly or life-span of battery will be reduced.
11. Please change the battery fully, before keep it for long time then recharge it per 3 months to prolong life-span of battery.
12. You had better not ride on a rainy day.
13. Battery, charger, electric wire, plug, enclosure and other parts of periodical check if damage, if have damage, and need to repair good impress, can continue to use.
14. "Transformers used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toy must not be used with this transformer until the damage has been repaired."
15. The toy is not intended for children under 3 years old.
16. The toy must only be used with the recommended charger.
17. The charger is not a toy.
18. Toys liable to be cleaned with liquid are to be disconnected from the charger before cleaning.
19. Check the equipped charger periodically and carefully.
20. Check the Harness, Socket, Accessories, and other Components all in good condition or not, repair or replace them if any problem found.

WARNING

1. Adult assemble only!
2. Choking hazard small parts, not for children under 3 yrs!
3. Don't give the tool to child in order to avoid open the protector on the top of the battery.

Assembly parts

1 x mains Charger	1 x seat
1 x Car Body	1 x front windscreen
1 x 1pair of front wheels	1 x Rear Spoiler
1 x 1pair of rear wheels	1 x Steering Wheel and column
4 x wheel caps/trims	1 x Fixing Kit