


CAMPINGGAZ®



CAMPING KITCHEN®



Camping Kitchen®




Camping Kitchen® Grill



Camping Kitchen® Plus



Camping Kitchen® Extra




Camping Kitchen® Plus - Camping Kitchen® Extra

Camping Kitchen® Grill


Camping Kitchen®

- 1**
- 2**
- 3**
- 4**
- 5**
- 6**
- 7**
- 8**
- 9**


1




2




3




CZ - BE - IE - HU - IT - LU -
NL - PL - PT - SE - UK



DK - ES
FI - NO





CH - DE
AT




FR


4




5




6




7




8




9




10




11




12



13



14






15



16



17



18



19





20




21

Camping Kitchen® Plus



Camping Kitchen® Extra

22




23



24



25



26



