



SRS-XB20


4-693-259-12(1)

©2017 Sony Corporation Printed in China




* 4 6 9 3 2 5 9 1 2 * (1)




1







DC IN 5V







CHARGE ⏱ 12 h : 00 m (500mA) CHARGE
 ⏱ 04 h : 00 m (1.5A)












2



Android iPhone







3



http://rd1.sony.net/help/speaker/srs-xb20/h_zz/





Android / iPhone

SongPal

<http://sonyapp.jp/songpal.html>