



MONTAGEANLEITUNG
INSTRUCTIONS DE MONTAGE
ASSEMBLY INSTRUCTIONS
MONTAGEAANWIJZING

micasa

980733


















4027.167-168 M-Budget KOMBI
 Schrank 2 Türen Buche







02.06 1/5


101 18x 8x30	102 12x 6,3x50	103 36x 3,5x15	104 6x	105 6x
108 2x 6,3x11	116 2x	111 4x	117 4x	107 2x
109 2x	110 2x	112 8x 4x25	113 11x 8x13	114 10x 3x15
115 1x				




1.




- 115 
- 1x
- 103 
- 3,5x15
- 111 








2.





- 101 
- 8x30

3.






- 105 
- 107 
- 103 
- 3,5x15
- 101 
- 8x30




4.




5.








6.




7.



8.



9.



10.

