






# ONE GB40 USER GUIDE.

**Reebok**  
**ONE** SERIES




D		G	
		F	
		D-29	
B D-32 D-33		C	
A D-34		E	
D-30 D-31		H	


1



2




3



4


- |  |   |
|--|---|
| <p>SCREW D-26<br/>M8*P1.25*16L ( 4 )</p> | <p>Curved washer D-28<br/>Ø8*Ø19*2T ( 2 )</p> |
| <p>Spring Washer D-35<br/>Ø8 ( 4 )</p>   | <p>Flat washer D-27<br/>Ø8*Ø19*2T ( 2 )</p>   |



5

- Screwdriver (1)
- 
- Knob E-4 (1)
- 


- SCREW C-4  
M5\*20L ( 1 )
- 




6




SCREW A-1  
M5\*10L ( 4 )




7



SCREW C-4  
M5\*20L ( 3 )



SPARE PARTS LIST



ITEM	DESCRIPTION	EVB SPEC	QTY		ITEM	DESCRIPTION	EVB SPEC	QTY	
A	Console	PE-ST65490016702	1	PCS	E-1	Screw	PD-SMM40855-1002	4	PCS
A-1	Screw	PD-SWM10510-1002	4	PCS	E-2	Flat washer	PD-WN240819-1002	4	PCS
B	Handlebar set	AA-A-PA3169-9014	1	SET	E-3	Nut	PD-NNM20800-1002	4	PCS
B-1	Foam grip	PL-P-PB4009-1002	2	PCS	E-4	Knob of handlebar	PL-P-PB6915-1000	1	PCS
B-2	Handlebar	PT-P-PB5023-1082	1	PCS	F	Front stabilizer set	AA-GB40FA04-9000	1	SET
B-3	Hand pulse	1PC1007-12B1	2	PCS	F-1	Front stabilizer	MT-GB40FW04-7002	1	PCS
B-4	Heart rate wire	B6120-E206500650-000	1	PCS	F-2	Nap	PL-P-PB2796L1002	4	PCS
B-5	Screw	PD-SUM10420-1002	2	PCS	F-3	Roller	PL-P-PB3031-1200	2	PCS
B-6	Semi Washer	PH-P-PB4109-1002	2	PCS	F-4	End cap	PL-P-PB5062-1A51	4	PCS
B-7	End cap	PL-P-PB1554L1002	2	PCS	F-5	Bushing	PH-P-PB3112-1000	2	PCS
C	Handlebar post set	AA-GB40FA02-9000	1	SET	F-6	C ring	PD-KC010800-1002	2	PCS
C-1	Handlebar	MT-GB40FW02-7002	1	PCS	F-7	Nut	PD-NQM10800-1002	2	PCS
C-2	Cable	B6020-C1115001-000	1	PCS	G	Rear stabilizer set	AA-GB40FA05-9000	1	SET
C-3	Tesion controller	PH-A84-0810-1002	1	PCS	G-1	Rear stabilizer	MT-GB40FW05-7002	1	PCS
C-4	Screw	PD-SWM40520-1002	4	PCS	H	Seat post set	MT-GB40FW03-7300	1	SET
D	Main frame set	AA-GB40FA01-9000	1	SET	H-1	Seat post	MT-GB40FW03-5000	1	PCS
D-1	Main frame	MT-GB40FW01-7002	1	PCS	H-2	Rail tube	MT-B2010FW047300	1	PCS
D-2	ilder spring	PH-P-PB1226-1000	1	PCS	H-3	Screw bracket of rail tube	PD-P-PB2293-1000	1	PCS
D-3	Nylon	PD-SEM10820-7600	2	PCS	H-4	Knob of seat	PD-P-PB6914-1000	1	PCS
D-4	Knob	PD-P-PB6913-1000	1	PCS	H-5	Flat washer	PD-WN321425-1041	1	PCS
D-5	Wire	B7030-D10650D6-260	1	PCS	H-6	End cap	PL-P-PB1577L1002	1	PCS
D-6	Screw	PD-SDM20410-1041	1	PCS	H-7	Left cover of rail tube	PL-C-GB500D-1002	1	PCS
D-7	Sensor bracket	PE-P-PB4310-1300	1	PCS	H-8	Right cover of rail tube	PL-C-GB501D-1002	1	PCS
D-8	Wave washer	PD-WD061725-1002	1	PCS	H-9	Screw	PD-SWM20506-1002	4	PCS
D-9	Flat washer	PD-WN121725-1002	1	PCS	I	Idler set	AA-A-PA3248-9000	1	SET
D-10	C ring	PD-KC011700-1002	1	PCS	I-1	Idler	MT-TUBRRFW04-5000	1	PCS
D-11	Bearing	PH-BA2-6203-1200	2	PCS	I-2	Jockey wheel	PH-P-PB3851-1000	1	PCS
D-12	Clamp	PL-P-PB2278-1002	1	PCS	I-3	Nut	PD-NNM20800-1041	1	PCS
D-13	Left crank	PH-P-PA-818-1041	1	PCS	I-4	Flat washer	PD-WN110825-1141	1	PCS
D-14	Right crank	PH-P-PA-819-1041	1	PCS	I-5	Screw	PD-SHM20820-1141	1	PCS
D-15	Belt	PH-LJ6M1066-1000	1	PCS	I-6	Wave washer	PD-WD061015-1002	2	PCS
D-16	Left cover (upper)	PL-C-GB5001-1002	1	PCS	I-7	Flat washer	PD-WN120612-1041	1	PCS
D-17	Right cover (lower)	PL-C-GB5011-1002	1	PCS	I-8	Screw	PD-SHM10612-1002	1	PCS
D-18	Screw	PD-SBM20516-1241	4	PCS	J	Magnet set	AA-A-PA3693-9000	1	SET
D-19	Screw	PD-SBM20440-1041	6	PCS	J-1	Screw	PD-SHM20616-1041	2	PCS
D-20	Tension controller, lower	PH-P-PB5076-1000	1	PCS	J-2	Spring washer	PD-WS210600-1041	2	PCS
D-21	Cap	PL-P-PB5862-1002	1	PCS	J-3	Flat washer	PD-WN120613-1041	2	PCS
D-22	Screw	PD-SHM20812-1102	3	PCS	K	Flywheel set	AA-A-PA3235-9102	1	SET
D-23	Pulley	PL-PJ6B2401-1002	1	PCS	K-1	Flywheel	PH-FAD25032E1002	1	PCS
D-24	Bushing	PH-P-PB3630-1000	1	PCS	K-2	Bearing	PH-BA2-6300-1000	1	PCS
D-25	Axle set	PH-P-PB5184-1000	1	PCS	K-3	Single bearing set	PH-P-PB3485-1000	1	PCS
D-26	Screw	PD-SRM40816-1002	4	PCS	K-4	Bearing	PH-BA2-6203-1100	1	PCS
D-27	Flat washer	PD-WN240819-1002	2	PCS	K-5	Flywheel axle	PH-P-PB4982-1000	1	PCS
D-28	Semi washer	PD-WA220819-1102	2	PCS	K-6	Flat washer	PD-WN113034-1002	1	PCS
D-29	Pedal	PS-P-PB5907-1302	1	SET	K-7	Pulley	PH-P-PB4842-1000	1	PCS
D-30	Saddle	PS-P-PB-240-1402	1	PCS	K-8	Bearing	PH-BA2-6900-1000	1	PCS
D-31	Cap of handlebar post	PL-C-GB5090-1002	1	PCS	K-9	Nut	PD-NNI21224-1041	5	PCS
D-32	Front cover of handlebar	PL-SB03-003-1002	1	PCS	K-10	Star washer	PD-NNI21224-1041	2	PCS
D-33	Rear cover of handlebar	PL-SB03-013-1002	1	PCS	K-11	Bushing	PH-P-PA-008-1000	1	PCS
D-34	Water bottle holder	PL-P-PB2074-1A51	1	PCS	K-12	Bearing	PH-BA2-6003-1000	1	PCS
D-35	Spring Washer	PD-WS220800-1102	4	PCS	K-13	Bushing	PH-P-PA-009-1000	1	PCS
E	Hardware kit	AA-GB40FA03-9000	1	SET					



[REEBOKFITNESSEQUIPMENT.COM/PRODUCTSUPPORT](http://REEBOKFITNESSEQUIPMENT.COM/PRODUCTSUPPORT)

**Reebok**  
**ONE** SERIES