











EGLO

32815/32817



H

OFF ON	OFF ON
	20%
	100%
	3000K → 6500K
	3000K → 6500K
10% 25% 50% 100% 	
	3000K 6500K
D1 D2	hold (D1) 3 sec → memorize settings → press (D1) (D2) → set memorize settings
RESET	hold (RESET) 3sec →