

PARTS LIST / LISTE DES PIÉCES

KEY #	ITEM #	DESCRIPTION	8742-52	8742-53	8742-56	8742-62	8742-63	8742-66	8743-52	8743-53	8743-56	8743-62	8743-63	8743-66
1	50909-E331	CASTING BOTTOM	1	1	1	1	1	1	1	1	1	1	1	1
2	66003-301	LID ASSEMBLY	1	1	1	1	1	1	.	.	.	.	.	.
	66003-304	LID ASSEMBLY	.	.	.	.	.	.	1	1	1	1	1	1
3	52019-911	FIRE BOX END CAP - LH	1	1	1	1	1	1	1	1	1	1	1	1
4	52019-931	FIRE BOX END CAP - RH	1	1	1	1	1	1	1	1	1	1	1	1
5	52049-042	HEAT SHIELD	2	2	2	2	2	2	2	2	2	2	2	2
7	Y-11544S	SCREW - BURNER	3	3	3	3	3	3	3	3	3	3	3	3
8	S21242	BURNER CLIP	3	3	3	3	3	3	3	3	3	3	3	3
12	52313-151	HOOD PANEL	1	1	1	1	1	1	1	1	1	1	1	1
13	52034-914	BOSS EXTENSION	1	1	1	1	1	1	1	1	1	1	1	1
18	52005-281	GRID - SINGLE CI	3	3	3	3	3	3	3	3	3	3	3	3
20	52004-991	GRID - WARMING RACK	1	1	1	1	1	1	.	.	.	.	.	.
	52004-992	GRID - WARMING RACK	.	.	.	.	.	.	1	1	1	1	1	1
21	59804-012	CONTROL ASSEMBLY	1	.	.	.	.	.	1	.	.	.	.	.
	59804-013	CONTROL ASSEMBLY	.	1	.	.	.	.	.	1	.	.	.	.
	59804-016	CONTROL ASSEMBLY	.	.	1	.	.	.	.	.	1	.	.	.
	59804-032	CONTROL ASSEMBLY	.	.	.	1	.	.	.	.	.	1	.	.
	59804-033	CONTROL ASSEMBLY	.	.	.	.	1	.	.	.	.	.	1	.
	59804-036	CONTROL ASSEMBLY	.	.	.	.	.	1	.	.	.	.	.	1
22	22024-904	COLLECTOR BOX	1	1	1	1	1	1	1	1	1	1	1	1
24	10111-18	CONNECTOR HOSE	1	1	1	1	1	1	1	1	1	1	1	1
25	52929-104D	BURNER	1	.	.	1	.	.	1	.	.	1	.	.
	52929-104E	BURNER	.	1	1	.	1	1	.	1	1	.	1	1
26	22001-769	CONTROL KNOB	3	3	3	3	3	3	3	3	3	3	3	3
26A	22001-669	CONTROL KNOB	.	.	.	1	1	1	.	.	.	1	1	1
27	22002-264	CONTROL BEZEL	3	3	3	3	3	3	3	3	3	3	3	3
27A	22001-164	CONTROL BEZEL	.	.	.	1	1	1	.	.	.	1	1	1
28	52004-814	CONTROL COVER	1	1	1	.	.	.	1	1	1	.	.	.
	52004-854	CONTROL COVER	.	.	.	1	1	1	.	.	.	1	1	1
31	52009-918	EDGE CAP - LH	1	1	1	1	1	1	1	1	1	1	1	1
32	52009-938	EDGE CAP - RH	1	1	1	1	1	1	1	1	1	1	1	1
34	S13473-073	HOSE-SIDE BURNER	.	.	.	1	.	.	.	.	.	1	.	.
	S13473-079	HOSE-SIDE BURNER	.	.	.	.	1	.	.	.	.	.	1	.
	S13473-109	HOSE-SIDE BURNER	.	.	.	.	.	1	.	.	.	.	.	1
34A	Y-11230	COTTER PIN	.	.	.	1	1	1	.	.	.	1	1	1
35	52039-101	SIDE BRACE	2	2	2	2	2	2	2	2	2	2	2	2
37	53139-908	SHELF BRACKET	4	4	4	4	4	4	4	4	4	4	4	4
38	Y-12620	SHELF LOCK CLIP	4	4	4	4	4	4	4	4	4	4	4	4
39	52044-111	BRACE - FRONT / REAR	2	2	2	2	2	2	2	2	2	2	2	2
41	10342-E13	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1
42	10342-E13	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	8742-52	8742-53	8742-56	8742-62	8742-63	8742-66	8743-52	8743-53	8743-56	8743-62	8743-63	8743-66
44	10342-42	ELECTRONIC IGNITOR	1	1	1	.	.	.	1	1	1	.	.	.
	10342-43	ELECTRONIC IGNITOR	.	.	.	1	1	1	.	.	.	1	1	1
44A	25070-925	WIRE - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1
44B	25070-93	BUTTON - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1
48	52004-007	GREASE PAN	1	1	1	1	1	1	1	1	1	1	1	1
49	51009-007	GREASE TRAY	1	1	1	1	1	1	1	1	1	1	1	1
50	52059-101	GREASE TRAY SUPPORT	1	1	1	1	1	1	1	1	1	1	1	1
51	52009-104	FLAV-R-WAVE ®	3	3	3	3	3	3	3	3	3	3	3	3
56	24004-12A	HANDLE	1	1	1	1	1	1	1	1	1	1	1	1
58	54009-936	BEZEL	2	2	2	2	2	2	2	2	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1	1	1	1	1	1
60	10571-6	HEAT INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1
65	20005-000	MATCH LIGHT - STICK	1	1	1	1	1	1	1	1	1	1	1	1
69	51274-131A	DOOR	1	1	1	1	1	1	.	.	.	.	.	.
	51274-134A	DOOR	.	.	.	.	.	.	1	1	1	1	1	1
70	21106-13	HANDLE	1	1	1	1	1	1	1	1	1	1	1	1
71	21070-13	BEZEL	2	2	2	2	2	2	2	2	2	2	2	2
78	56039-211	MAGNET BRACKET	1	1	1	1	1	1	1	1	1	1	1	1
80	51189-101	SIDE PANEL	2	2	2	2	2	2	2	2	2	2	2	2
81	Y-11992	SCREW 1/4-20 x 2 1/4	4	4	4	4	4	4	4	4	4	4	4	4
82	51604-104	BASE TRIM	1	1	1	1	1	1	1	1	1	1	1	1
87	Y-11793	NUT 1/4-20	4	4	.	4	4	.	4	4	.	4	4	.
88	21303-921	PANEL - REAR	1	1	1	1	1	1	1	1	1	1	1	1
90	51624-131	BASE	1	1	.	1	1	.	1	1	.	1	1	.
	51624-171	BASE	.	.	1	.	.	1	.	.	1	.	.	1
99	32001-151	CASTOR BRACKET CAP	4	4	4	4	4	4	4	4	4	4	4	4
100	51639-108	CASTOR BRACKET	2	2	2	2	2	2	2	2	2	2	2	2
101	51039-101	CASTOR BRACKET SUPPORT	2	2	2	2	2	2	2	2	2	2	2	2
102	10892-286	CASTOR	4	4	4	4	4	4	4	4	4	4	4	4
103	21039-301	TANK BRACKET	1	1	.	1	1	.	1	1	.	1	1	.
107	Y-12870	WASHER	6	6	6	6	6	6	6	6	6	6	6	6
113	10342-T14	SIDE BURNER ELECTRODE	.	.	.	1	1	1	.	.	.	1	1	1
114	53150-614	SHELF - RIGHT	1	1	1	1	1	1	1	1	1	1	1	1
115	53150-634	SHELF - LEFT	1	1	1	.	.	.	1	1	1	.	.	.
	53150-654	SHELF - SB - LEFT	.	.	.	1	1	1	.	.	.	1	1	1
123	Y-12117	BUSHING	.	.	.	2	2	2	.	.	.	2	2	2
124	23000-271	SIDE BURNER BODY	.	.	.	1	1	1	.	.	.	1	1	1
125	23000-253	SIDE BURNER COVER	.	.	.	1	1	1	.	.	.	1	1	1
126	10390-R81A	SIDE BURNER	.	.	.	.	1	1	.	.	.	.	1	1
	10390-R81D	SIDE BURNER	.	.	.	1	.	.	.	.	.	1	.	.
127	Y-12871	SCREW M4 X 0.7	.	.	.	2	2	2	.	.	.	2	2	2

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8742-52</u>	<u>8742-53</u>	<u>8742-56</u>	<u>8742-62</u>	<u>8742-63</u>	<u>8742-66</u>	<u>8743-52</u>	<u>8743-53</u>	<u>8743-56</u>	<u>8743-62</u>	<u>8743-63</u>	<u>8743-66</u>
128	23009-951	GRID	.	.	.	1	1	1	.	.	.	1	1	1
140	S21125S	SCREW #8 X 1/2	6	6	6	6	6	6	6	6	6	6	6	6
141	Y-11559	BOLT 1/4-20 X 1	2	2	2	2	2	2	2	2	2	2	2	2
144	Y-12220	BUSHING	.	.	1	.	.	1	.	.	1	.	.	1
145	S21235	HINGE PIN	2	2	2	2	2	2	2	2	2	2	2	2
146	S21233	HITCH PIN CLIP	2	2	2	2	2	2	2	2	2	2	2	2
147	Y-11231	LID BUMPER	4	4	4	4	4	4	4	4	4	4	4	4
148	10240-20	DOOR PIN	1	1	1	1	1	1	1	1	1	1	1	1
149	Y-11551	SHOULDER SCREW 1/4-20 X 1	1	1	1	1	1	1	1	1	1	1	1	1
150	Y-12124	DOOR PIN CAP	1	1	1	1	1	1	1	1	1	1	1	1
151	Y-12857	WASHER	2	2	2	2	2	2	2	2	2	2	2	2
152	Y-12234	MAGNET	1	1	1	1	1	1	1	1	1	1	1	1
153	Y-12223	MAGNET - PUSH IN	1	1	1	1	1	1	1	1	1	1	1	1
154	Y-12129	WIRE CLIP	2	2	2	2	2	2	2	2	2	2	2	2
155	S21124	SCREW #8 X 1/2	8	8	8	8	8	8	8	8	8	8	8	8
158	Y-12646	SCREW SHOULDER #8 X 1/2	.	.	.	2	2	2	.	.	.	2	2	2
159	S21127S	SCREW #8-32 X 7/16	6	6	6	8	8	8	6	6	6	8	8	8
160	Y-29304	SCREW #10-24 X 3/8	6	6	6	6	6	6	6	6	6	6	6	6
161	Y-12310	SCREW 1/4-20 X 3/4	8	8	8	8	8	8	8	8	8	8	8	8
163	S35094	SCREW #10-24 X 5/8	4	4	4	4	4	4	4	4	4	4	4	4
181	25030-73	WIRE - BATTERY PACK	1	1	1	1	1	1	1	1	1	1	1	1
181A	25070-95	LIGHT SWITCH	1	1	1	1	1	1	1	1	1	1	1	1
184	25080-80	BATTERY PACK	1	1	1	1	1	1	1	1	1	1	1	1
186	Y-12865	SCREW 1/4-20 X 3/4	46	46	42	46	46	42	46	46	42	46	46	42
190	25020-83	WIRE - LED LIGHT	1	1	1	.	.	.	1	1	1	.	.	.
	25020-84	WIRE - LED LIGHT	.	.	.	1	1	1	.	.	.	1	1	1





