




**MONTAGEANLEITUNG**  
**INSTRUCTIONS DE MONTAGE**  
**ASSEMBLY INSTRUCTIONS**  
**MONTAGEAANWIJZING**

micasa

980733

















4027.167-168 M-Budget KOMBI  
 Schrank 2 Türen Buche







02.06 1/5


101  18x 8x30	102  12x 6,3x50	103  36x 3,5x15	104  6x	105  6x
108  2x 6,3x11	116  2x	111  4x	117  4x	107  2x
109  2x	110  2x	112  8x 4x25	113  11x 8x13	114  10x 3x15
115  1x				




1.




- 115 
- 1x
- 103 
- 3,5x15
- 111 








2.





- 101 
- 8x30

3.






- 105 
- 107 
- 103 
- 3,5x15
- 101 
- 8x30




4.




5.







6.




7.



8.



9.



10.

