

CHANGE YOUR CLASSIC SKINS

HOW TO



WHY CHANGE THEM

There are two reasons why you should change your skins: your old skins don't have enough grip anymore **or** you want to adapt to snow conditions and to your technical ability. You can encourage gliding or grip by changing skin type.

HOW TO CHANGE THEM

Simply remove the skin from the ski base starting at the tip and finishing at the tail. Stick them with the sticky sides together to store them. Lie the new skins down on the ski base taking into account the direction of the fibers on your skins. Apply pressure with your thumbs, this time starting at the tail and moving up to the tip, to stick the new skins on.

Generally, you should change your skins once a year. You can clean your skins by applying a special product and brushing against the fibers, with a cloth. To improve the performance of your skins, you can apply a water repellent product, however this time apply it in the same direction as the fibers.